

ELECTRICAL SYSTEM

KEY TO THE WIRING DIAGRAM

No. Description

1. L.H. pilot lamp and front flasher
2. L.H. head lamp
3. R.H. head lamp
4. R.H. pilot lamp and front flasher
5. Direction switch and horn push
6. R.H. horn
7. Distributor
8. L.H. horn
9. Ignition coil
10. Stop lamp switch
11. Starter
12. Overdrive solenoid (when fitted)
13. Gearbox switch
14. Throttle switch (when fitted)
15. Flasher relay
16. Dynamo
17. Control box
18. Heater motor (when fitted)
19. Overdrive relay (when fitted)
20. Starter solenoid
21. Flasher unit
22. Ignition switch
23. Starter switch

No. Description

24. Flasher warning lamp
25. Lighting switch
26. Heater switch (when fitted)
27. Wiper motor
28. Dip switch
29. Panel light
30. Panel light
31. Panel light
32. Fuel gauge
33. Petrol pump
34. Panel lamps switch
35. Wiper motor switch
36. High beam warning lamp
37. No charge warning lamp
38. Cigar lighter (when fitted)
39. Overdrive switch (when fitted)
40. 12 volt battery
41. Tank unit
42. Battery master switch
44. L.H. stop and tail lamp and rear flasher
45. Number plate lamp
46. R.H. stop and tail lamp and rear flasher

COLOUR CODE

| | | | |
|----|-------------------|----|-------------------|
| U | BLUE | GN | GREEN with BROWN |
| UR | BLUE with RED | GB | GREEN with BLACK |
| UW | BLUE with WHITE | Y | YELLOW |
| W | WHITE | YG | YELLOW with GREEN |
| WR | WHITE with RED | N | BROWN |
| WG | WHITE with GREEN | NU | BROWN with BLUE |
| WP | WHITE with PURPLE | NG | BROWN with GREEN |
| WN | WHITE with BROWN | NP | BROWN with PURPLE |
| WB | WHITE with BLACK | NB | BROWN with BLACK |
| O | GREEN | R | RED |
| OR | GREEN with RED | RW | RED with WHITE |
| GY | GREEN with YELLOW | B | BLACK |
| GU | GREEN with BLUE | BG | BLACK with GREEN |
| GW | GREEN with WHITE | LG | LIGHT GREEN |
| GP | GREEN with PURPLE | WU | WHITE with BLUE |