

Notes

* Grounds are functional not physical
* Extend wires to new fusebox with period single pin bullet connector or inline splice.
* Inline splice: use crimp butt-splice covered with black heat-shrink tubing.
* Inline fuse: use shortest possible lead, soldered or but-spliced and covered to the holder with black heat-srink tubing.
* Fastons: use non-insulated with 1" black heat-shrink tubing.

Austin-Healey	Electrical Harness	Rev 0.1	06-Sept-2016	Page 1